

easicook.co.uk

Spare Parts Manual

**Leading UK Distributors
of Catering Equipment Since 1977**

Sales - Repairs - Spares

Tel: 029 20747567

Fax: 029 20214100

Email: info@easicook.co.uk

[Click Here for Live Online Chat](#)


PARTI DI RICAMBIO
PIECES DETACHEES
SPARE PARTS
ERSATZTEILE
LISTA DE RECAMBIOS

LBC 210

10/97

LBC 215
LBC 215 A
LBC 275
LBC 275 A


9/94



02 - 1999 S. AG.

LBC215


Hood



02 - 1999 | S. AG. 01




LBC215

Wash




LBC215

Wash arm




LBC215

Rinse assembly





LBC215
Rinse aid injector




02 - 2004 | S. AG.

LBC215


Wash pump

100702
 220/240 V
 50 Hz HP 0,3
 Kw 0,22



100701
 220/240 V
 50 Hz HP 0,2
 Kw 0,15





631208
 (5 μ F)

02 - 1999 S. AG.

LBC215

Control box



02 - 2001 S. AG.